



Double Wall Reusable Tea Infuser

CARE AND USAGE GUIDE

- Medium 350 ml | 17 fl oz
- Made with premium borosilicate glass
- Drop in stainless steel tea infuser
- Cool touch glass



USAGE

- Separate all parts and hand wash before use and after each use.
- Take care when removing tea infuser basket from bottle.
- Never overfill flask and ensure lid is properly fitted to base.
- Recommend pouring liquid into heat proof mug/cup.
- Contents may be hot.
- Hand wash only.



WARNINGS

- To prevent injury allow very hot liquid to cool to drinking temperature before closing lid.
- Glass is a fragile material and may break upon impact.
- Avoid sudden or severe temperature changes.
- Glass is breakable and must be handled with care to avoid personal injury or property damage.
- Do not use if glass is chipped, cracked or has significant scratches.
- Not suitable for freezer or microwave use.
- Not dishwasher safe.
- Do not carry cup containing liquid in bags in case of accidental opening.