

rice cooker

Fluffy rice everytime!



Cook all kinds of rice and grains.

For first time use refer to packet instructions for indicative cooking times.

Stop and check cooking progress at regular 5 minute intervals.



white long grain



brown



short arborio



quinoa

Steps for white long grain rice

1



Measure 2 cups of rice & add to cooker.

Add 4 cups of cold water and stir.

Makes 4 serves

2



Microwave on high for 17 minutes without the lid.

Cooking guidelines and recipes are based on a 1000W microwave. It is recommended that you monitor and check the water level during cooking and top up as required.

3



Remove from microwave and put lid on with vent open.

Rest for 5 minutes.

Loosen grains with rice paddle and serve.

MAKES 1 TO 4 SERVES IN MINUTES

easy recipes

Find recipes at
www.decor.com.au

Care guidelines for Microsafe™ Rice Cooker

Before use, remove the labels and wash by hand or in the dishwasher. Do not use abrasive materials when hand washing. The steam release vent can be easily removed from the lid for cleaning. Freezing causes a storer to become temporarily stiff, making it difficult to remove the lid. Once removed from the freezer, we recommend that you allow it to rest at room temperature for a few minutes, or run warm water over it for a few seconds. The lid will then be easy to remove.

WARNING: Overheating of foods high in oil, fats or sugar may cause the product to melt. Heating of any such substances must be carefully monitored (e.g. checked every 30 seconds) and such substances should not be further heated once melted.

IF THIS PRODUCT MELTS WITH HOT CONTENTS, THERE MAY BE A RISK OF BURN INJURY.

Do not use Decor Microsafe™ products: • On hot plates • For popping corn • In conventional or combination microwave ovens

Decor is a registered trade mark and Microsafe and Microsafe Circles are trade marks of The Decor Corporation Pty. Ltd., Melbourne, Australia. © 2019

BPA FREE